


Safe Handling of UV-Curable Materials



UV-Cure Technology

Conventional coatings are generally dissolved in organic solvents or dispersed in water. Curing (or hardening) then proceeds by solvent evaporation and/or a chemical reaction. In the case of UV-curable coatings, the curing reaction is initiated by exposure to intense ultraviolet light.

A light source which emits energy having a wave length of 200-400 nanometers is used to activate a photoinitiator contained in the product. This begins the polymerization, or curing, process which is completed in a few seconds or less. In general, UV-curable materials require less energy, less time to cure and contain less volatile materials than conventional products.

Typical components of DSM Desotech's UV-curable products may include: a reactive resin, a multifunctional crosslinker, a reactive diluent and, in some cases, a solvent (or solvents) to aid in application.

Depending upon end-use and application, these components may be formulated with photoinitiators, stabilizers, pigments and other additives. The following general categories best describe the chemistry used in our UV-curable products:

Acrylates. Acrylate-based materials are cured by a free radical mechanism and utilize oligomers and multifunctional and monomeric reactive diluents. Vinyl monomers, acrylated epoxies and urethanes are often included for hardness, toughness, and good physical properties.

Epoxies. Epoxies are polymerized cationically by the photolysis of an initiator. Hydroxyl-containing intermediates are also commonly included in these systems as co-reactants.

Unlike free radical initiated UV systems which cure primarily in the areas

UV-Curable Technology	1
Storage of UV-Curable Materials	2
Transfer and Handling	3
Safe Use of Curing Equipment	4
Spray Application	4
Toxicity	5
Exposure Control	6
Clean-Up	7
Disposal and Maintenance	8
Fire Fighting	9
First Aid	9

DSM Desotech is a leading developer of high-performance UV-curable materials for a variety of today's top industries. Our products include DeSolite[®] coatings and adhesives, Cablelite[™] inks and matrix materials, and DSM Somos[®] solid imaging materials.

Formulated differently than conventional materials, UV-curable products require particular instruction for their safe handling. The information provided in this guide is designed to acquaint you with UV-cure technology, identify its potential hazards, and provide direction and guidelines for the safe application and efficient use of DSM Desotech UV-curable products.

By following the precautions outlined in this guide, in combination with the instructions provided on our product labels and Material Safety Data Sheets, DSM Desotech UV-curable products can be safely handled in most every workplace.

of direct light exposure, the cationically initiated epoxy systems will continue reacting after the UV source is removed and do not depend on the generation of free radicals.

Storage of UV-Curable Materials

UV-curable materials are composed of reactive monomers and oligomers. If improperly stored, these compositions may undergo polymerization with the evolution of heat. Improperly stored UV materials increase in viscosity and eventually result in a gelled (polymerized) product in the storage container.

For this reason, products should always be stored according to storage and handling recommendations, as well as applicable fire department and insurance recommendations.

Containers

Most DSM Desotech products are supplied in lined (baked phenolic) steel, plastic or fiber containers with plastic linings or inserts. Polyethylene bottles or liners are acceptable as long as they are opaque to ultraviolet light and not used to hold solvent-containing materials.

UV-curable products containing acrylates should not be allowed to come in contact with iron, copper or copper-containing alloys to insure product stability. Plastic containers made from organic soluble materials such as polystyrene or polyvinyl-chloride (PVC) should not be used for storage.

Container lids should be tightly sealed in order to protect UV products from contamination and/or stray light when not in use. Also, a tightly sealed container will prevent product spillage if the container is accidentally dropped during handling.

Shelf Life

Most DSM Desotech products are usable for at least six months from the

date they are shipped. Provisions should be made to insure inventory rotation: first in, first used.

In general, UV-curable products are usable for periods up to one year or even longer. DSM Desotech products are marked with a retest date on the label. This date is determined through the use of retain program and indicates when the product should be checked by Desotech prior to its use.

Light

UV-curable materials should be shielded from sunlight or other sources of actinic radiation such as fluorescent or mercury vapor lights. Exposure to actinic radiation will lead to increased product viscosity and eventually to product polymerization.

Temperature

Containers or bulk storage tanks containing UV materials should be kept indoors at temperatures between 15°C (59°F) and 30°C (86°F). Temperatures above 30°C will accelerate the depletion of the stabilizers contained in the product. Once the stabilizers are exhausted, polymerization will occur.

For pigmented materials, elevated temperatures will increase the rate of pigment settling. Refer to specific data sheets for individual products.

Temperatures below 15°C may lead to phase separation (individual components separating from solution) or possible precipitation of stabilizers. If the product is believed to have been below 15°C for a prolonged period of time, it should be checked for performance before being used in production.

Product that has undergone phase separation can be fully restored to initial properties by gently warming and mixing the contents of the container. Care should be taken not to induce bubbles into the material during mixing.

Contamination

Free radical sources, such as peroxides and iron contaminants, can initiate polymerization of acrylate based products. Epoxy based products will undergo rapid polymerization when contaminated with strong acids.

Introduction of free radical scavengers (phenolic compounds and others) will retard the cure rate of acrylate based products. Alkali or amine contamination will retard the cure rate of epoxy based products. Accidental contamination with polymerization inhibitors will result in slower cure speed.

It is also important to prevent accidental product contamination with organic solvents or water. Dilution of UV-curable products with non-reactive solvents will result in slower cure speed, if they are not first evaporated.

Polymerization

Signs of polymerization include bulging or leaking containers, or the emission of heat or unusual odor from the container. The following steps should be followed if polymerization is suspected (particularly in the case of drums or other large containers):

First, all unnecessary personnel should be evacuated from the area. Heat input, if utilized, should be discontinued and cooling initiated immediately through internal coils, external heat exchangers or cold water spray.

If polymerization of an acrylate-based product continues, as evidenced by a continued increase in temperature, one part of a solution of 15% Phenothiazine dissolved in Glycol Ether DB Acetate (Diethyleneglycol n-butyl ether acetate) should be added to 10 parts material and mixed thoroughly with air sparging and/or mechanical agitators or diaphragm type pumps. Inhibitor solution should be kept on hand for emergency use. Disposal should be in compliance with local legislation.



Premature polymerization of a cationically curable material can be quenched by adding 5 parts of a 1/1 isopropanol/water solution to 100 parts of coating. Add the solution with vigorous stirring to insure complete quenching of polymerization.

Transfer and Handling

The manner in which UV-curable materials are transferred from shipping container to application equipment will depend on many factors including: volume of usage, container size and type of coating equipment.

Consult DSM Desotech on the design of an appropriate transfer system to suit specific needs. The following fundamental considerations must be taken into account in designing a successful material transfer system.

Composition of Transfer Equipment

All transfer lines, hoses and fittings should be made of a material which is opaque, essentially non-reactive, and not affected by UV-curable material (such as stainless steel). Some plastics, such as polyethylene or Teflon®, may also be used as long as they are not affected by the UV material and are opaque to ultraviolet light. Otherwise, curing may take place in the tubing with some ultraviolet systems.

Avoid any alloys containing copper or iron, which may result in premature curing (polymerization) and color degradation.

Pumps and Pressurized Air

It is generally advisable to avoid high shear pumps such as gear or piston

types because the high degree of shear may cause the coating to cure and the pump to seize. When using pumps, peristaltic or diaphragm pumps are usually preferred.

Pressurized air can also be used to transfer products, if all of the vessels and lines are certified and capable of resisting the air pressure. A maximum air pressure of 0.35 MPa (50 psi) is suggested. If air pressure is used, make sure the air is clean and dry. *Avoid using nitrogen gas, which can cause gellation.*

Flammability

The degree of flammability hazard is often expressed as the flash point of a material or the temperature to which a material must be heated before a flame will ignite the vapors. In general, DSM Desotech products without solvents have a flash point greater than 93°C (200°F). Products containing solvents will be flammable or combustible.

Special precautions should be taken to prevent exposure of UV-curable materials to heat, flames, sparks or any source of ignition. Containers exposed to extreme heat may explode. Follow appropriate bonding and grounding procedures when transferring UV-curable materials.

In cases where flammable organic solvents are contained in the product, they should be thoroughly evaporated and exhausted before curing begins. Special care must be taken to insure that the atmosphere in the curing chamber is well exhausted or non-flammable, as most curing equipment is not certified as "explosion proof."

Warming

In some cases, material will need to be heated for application or transfer. If this is necessary, it is advisable to apply heat slowly and uniformly. Preferred heating methods include circulating hot air, a water bath, or circulating oil. Although it takes longer, these methods are generally uniform and can be reliably controlled.

Heating belts and immersion heaters should always be avoided because they produce hot spots and tend to have poor thermostatic control.

Adequate ovens or baths can be purchased or built for small containers. For large volume usage in drum quantities, it is generally recommended that a hot room or preheat tank be installed to provide an adequate and continuous production feed.

Should transfer lines require heating to assist in transfer, water jacketing is recommended. Although moderate heating can be used, localized overheating (above 70°C or 160°F) should be avoided.

Agitation

Under normal storage temperatures, DSM Desotech's clear UV-curable products do not need agitation. However, pigmented materials, such as Cablelite™ inks do require rolling to insure against pigment settling. In the case of colloidal suspensions, such as DeSolite® organic/inorganic hard-coats, a small amount of agitation maybe required to redisperse a small amount of particle settling.

If agitation is required, small round containers can be rolled on a flat surface. Large containers will require slow mixing with an agitator. Prior heating to lower viscosity will assist in the agitation of high viscosity materials. Care should be taken not to induce bubbles during mixing.

Handling

During warming and transfer steps, it

is essential to protect UV-curable materials from exposure to light and contaminants of any sort. Therefore, it is recommended that the containers be covered but vented to avoid any pressure buildup.

Ultraviolet absorbing plastic sleeves should be installed over fluorescent lights in work or application areas to prevent premature curing of the product. Likewise, windows should be covered with a plastic barrier or film that will screen out ultraviolet light.

Before using any metal tanks or pipes, it is essential to thoroughly clean and flush the system before introducing the material. All transfer lines and pumps should be blown clear with clean, dry air following completion of transfer.

Adequate ventilation must be provided in preparation or application areas, as small amounts of vapors may be emitted.

Safe Use of Curing Equipment

The application of ultraviolet curing requires the use of specialized curing equipment which utilizes electricity to accomplish the curing mechanism. The electricity is converted into ultra-violet light which initiates a photochemical reaction and polymerization. The generation of heat during this process is purely coincidental.

Commercially available UV-curing equipment can be designed for most industrial environments. Like other industrial equipment, it contains hazards which must be understood in order to maintain a safe workplace. A well written operating/maintenance/safety manual should be developed with the equipment manufacturer for each piece of curing equipment.

Since UV-curing technology involves equipment which is different from

conventional thermal drying/curing systems, it is suggested that the following guidelines be followed in equipment selection:

Equipment should be purchased from reputable manufacturers and should meet all current safety standards and relevant governmental regulations. Where applicable, the equipment manufacturer should supervise installation of the equipment to insure its proper operation.

The equipment manufacturer should thoroughly train operators in the proper operation of the equipment. Instructions must emphasize a complete understanding of the hazards associated with the equipment, as well as the type and location of the safety devices included.

A detailed instruction manual should be available in the workplace for each piece of equipment. Concise safety and operating instructions should be prominently posted in the work area.

A professionally designed exhaust and ventilation system should be a part of each UV processor. Such a system will prevent the buildup of ozone and oxygen depletion (where an inert gas such as nitrogen is used). Furthermore, it will remove any chemical species which may be volatilized during the application or curing of the coating materials.

In addition to the generalized safety conditions associated with UV curing equipment, there are other hazards to be considered including: ultraviolet or electron/x-ray radiation leakage due to equipment damage, improper maintenance or abuse.

UV curing equipment produces high intensity ultraviolet light. There are three usual means of generating UV energy including mercury arc lamps, pulsed lamps (xenon flash) and electrodeless lamps. In each case, ultraviolet light is emitted from a rare gas,

metal vapor or metal halide plasma contained in a sealed quartz tube.

Somos[®] stereolithography resins are imaged with lasers which emit in the ultraviolet light. Stereolithography equipment is designed to limit opportunities for worker exposure to the intense light emitted by the laser. It is critical that the equipment is maintained in good working order and that safety devices are not defeated.

Removal of guards, optical maintenance and laser tuning should be performed only by trained personnel. Eye protection which filters out 300 - 400 nm UV light should be worn by lab personnel while laser/optical maintenance is performed, and non-essential personnel should be restricted from areas where they may be exposed to UV laser light.

All UV curing systems must provide safeguards against employee exposure to the generated light, ozone, high voltage and hot exposed areas. To prevent skin burns, contact with hot areas on curing equipment should be avoided.

Spray Application

Recent interest in spray application of UV-curable materials has raised questions regarding the potential hazards of worker exposure to mists and aerosols of multifunctional acrylates, oligomers, and other low volatility reactive species. Potential hazards associated with spray application vary with the particular formulation (i.e., the specific acrylate or cationic epoxy chemistry employed).

Very often, UV-curable products for spray application will be formulated with solvents instead of, or in addition to, reactive diluents for control of application properties. The use of solvents in UV-curable systems means that the user of these materials must protect against exposure to heat,



sparks and flames, as well as the hazards associated with the reactive chemical constituents. Safety and ventilation techniques appropriate for any solvent-borne coating must be followed.

Control of Exposure

The following recommendations should be closely adhered to:

Engineering controls are the preferred method for reducing employee exposure. This includes the use of local exhaust ventilation in the form of spray booths. Explosion proof construction may be required. All ventilation equipment should be electrically bonded and grounded.

It is required that UV-curable materials be spray applied in conveyORIZED, automated, and enclosed booths to eliminate worker exposure to overspray which may be harmful if inhaled or allowed to come in contact with the skin or eyes. Spraying of complex parts may require robots to eliminate hand application and worker presence in the spray booth.

Appropriate approved respirators must be utilized where engineering controls are not adequate. In no case should products containing acrylate monomers be applied in production by hand spray!

Measurement of airborne concentrations of solvents, acrylates and other coating system components should be performed by a qualified industrial hygienist at the startup of an operation and routinely thereafter to insure continued effective control of potential inhalation hazards. The ventilation

system should be routinely checked to insure adequate exhaust.

Equipment Considerations for Spray

UV-curable materials present new problems for equipment suppliers because of their reactivity and thermal sensitivity. Airless spray is generally unsuitable for solventless coating formulations because high instantaneous temperatures are generated by friction in the seals and pistons of hydraulic pumps causing gelation and pump seizure.

Solvent diluted UV-curable materials should be tested for compatibility with airless spray equipment on an individual basis. High speed turbine bells may provide the means of applying solventless, non-volatile UV-curable products without addition of solvents. Where applicable, electrostatic spray can be used.

The overspray of UV curable materials does not "dry" to a hard film but rather remains "wet" until exposed to UV light. Spray booths should be lined with a fiber matting type material that can be exposed to UV light or passed through the UV processor to cure the wet film. The lining material can then be disposed of in a suitable manner.

Water treatment considerations associated with water wash spray booths should not be that different with UV- curable products than with conventional coatings, but this should be determined on an individual case basis through discussions with regulatory agencies.

All piping should be stainless steel or suitable plastic. Care should be taken

to avoid bare steel, copper, or brass, which may contaminate the coating (see "Transfer and Handling" section).

Toxicity

Any chemical may exert harmful effects if it enters the body in sufficient quantity. The hazard of a chemical is the likelihood that a chemical will produce damage under specified conditions and is derived from two main considerations:

Toxicity. Toxicity is the inherent ability of a chemical to produce a deleterious response in a biological system. All materials have some toxicity associated with them which may be high or low. Toxicity can be measured in a quantitative manner through experiments which determine the nature of the toxic effect and the dose which will cause it.

Process Conditions. The industrial process determines the probability and extent to which exposure to the chemical can occur.

In evaluating the toxicity of DSM Desotech/DSM Somos products, the toxicity of all hazardous components must be considered.

Skin Irritation

Brief contact with high concentrations, or prolonged exposure to a low concentration, of acrylate-containing materials may cause tissue inflammation, itching, redness, dry patchy scaling and/or discharge. Skin irritation is generally confined to the area of direct contact. Prolonged exposure may cause burns.

Because direct skin contact with acrylates generally does not cause immediate irritation, skin exposure can easily go unnoticed. Contact with epoxy-containing UV-curable materials may also cause skin irritation.

Skin Sensitization

Sensitization dermatitis is the result of an allergic reaction to a given substance. Direct skin contact is necessary to cause sensitization. Individuals may become sensitized to a substance after a trouble-free period of exposure.

There are many factors which affect a person's susceptibility, including existing skin diseases, personal habits, and individual sensitivity. Once a person is sensitized, even a minute exposure may trigger a severe outbreak of dermatitis which may spread over the body. Sensitization is generally permanent, so a sensitized individual should be removed from potential contact with the sensitizer.

All UV-curable materials are potential sensitizers. To avoid skin sensitization, Do not allow uncured material to contact skin. Consult Material Safety Data Sheets for specific information about the sensitization potential of UV-curable materials.

Eye Irritation

UV-curable materials will cause moderate to severe eye irritation upon direct contact.

Inhalation

Inhalation of UV-curable materials has been regarded as less of a problem than skin or eye contact due to their low volatility—though volatility does vary by composition. Vapors, however, may accumulate in areas without adequate ventilation. Acrylate vapors will irritate the nose, throat and lungs. All areas where acrylates or epoxies are handled should be thoroughly ventilated.

Volatile organic solvents contained in some UV materials may cause irritation of the respiratory tract or acute nervous system depression characterized by headache, dizziness, staggering gait or confusion.

Exposure to extremely high airborne solvent levels as may be found in confined spaces may lead to unconsciousness, coma or death. Some reports have associated prolonged and repeated occupational over-exposure to solvents with permanent brain and nervous system damage.

In spray applications, the coating ingredients are atomized directly into the air and thus may be inhaled. Breathing spray mist may irritate the respiratory tract. The possibility that inhalation of the spray mist may result in respiratory sensitization must also be considered.

Occupational Exposure Limits

Neither the U.S. Occupational Safety and Health Administration (OSHA) nor the American Conference of Governmental Industrial Hygienists (ACGIH) has established occupational exposure limits for the majority of the acrylates contained in UV-curable materials. Consult the Material Safety Data Sheet for information regarding exposure limits of specific material components.

Ingestion

UV-curable materials may be toxic by ingestion. These materials must not be present where food and drink are stored, prepared or consumed.

Carcinogenicity

While DSM Desotech avoids the use of carcinogenic ingredients where possible, their presence in a Desotech product is specifically noted on the Material Safety Data Sheet.

Toxicity of the Cured Coating

After curing, DSM Desotech products exist as a cross-linked material which should present no hazard to health under normal use conditions. However, if the cure is not complete, low levels of volatile components may still remain. If these volatilize in an area with poor ventilation, irritating airborne contaminant levels may develop. Moreover, skin contact with incom-

pletely cured material may result in skin sensitization.

Burning of the cured material may result in toxic gas formation depending on such factors as temperature, amount of oxygen present, and the specific formulation.

Exposure Control

There are three types of controls utilized to reduce exposure to chemicals:

Engineering controls are the preferred method for reducing employee exposure and include local exhaust ventilation and closed process systems.

Administrative controls include rotating employees to different jobs in order to reduce the exposure time to hazardous materials. Reduced exposure time does not correspond to a reduction in the risk of sensitization, and the number of employees exposed to the material is increased by using job rotation. Thus, this approach is not useful in protecting employees against sensitization.

Personal protective equipment is utilized in cases where engineering or administrative controls are not feasible or adequate.

For UV-curable materials, the following personal protection equipment and controls are recommended:

Skin Protection

Chemically resistant gloves should be worn at all times when working with UV-curable materials. In cases where fine work is being performed, disposable nitrile gloves may provide some protection but should be used only for brief periods. Glove manufacturers should be consulted as to appropriate gloves.

When handling large quantities of UV-curable materials, long-sleeved,



chemically resistant uniforms should be worn, including both tops and bottoms. Disposable uniforms provide only limited protection against UV-curable materials. Shoe coverings such as rubber boots or disposable booties should also be utilized.

Eye Protection

Safety glasses with side shields will provide adequate protection when working with small quantities of UV-curable material. Face shields should be used where exposure to large quantities is possible. Contact lenses should not be worn.

Respiratory Protection

Respiratory protection is often not necessary if engineering controls are implemented and if low volatility materials are used. However, the need for respiratory protection must be evaluated for each use of a UV-curable material.

If respiratory protection is utilized, a respiratory protection program complying with 29 CFR 1910.134 must be implemented. A NIOSH/MSHA* approved half mask or full face respirator with organic vapor cartridges may be used if airborne contaminant levels do not exceed ten times the occupational exposure limits.

DSM Desotech does not recommend that employees hand spray acrylate based UV-curable materials. If an employee is involved in spraying epoxy-based UV-curable materials, a NIOSH/MSHA approved air supplied respirator would provide the best protection.

NIOSH/MSHA approved full face respirators with spray paint cartridges

(pre-filters and organic vapor cartridges) may also provide protection. See "Spray Application" section for additional information.

Work Uniforms

Work uniforms should not be taken home for cleaning. Laundering of work uniforms should be performed by a professional laundry. Inform the laundry of the presence of UV-curable materials. It may be advisable to segregate uniforms worn while working with UV-curable materials containing acrylates from other soiled uniforms to avoid cross-contamination.

Hygiene

Good hygienic practices should be rigorously followed including washing before meals, breaks, smoking, applying cosmetics, using toilet facilities and after work. Moisturize hands after the skin is washed after work to prevent drying.

Safety Shower and Eye Wash Stations

Safety showers and eye wash stations should be installed in the work areas in all locations necessary to insure ready employee access in case of exposure. Employees should be trained in their use. Generally, if an exposure has occurred, the affected employee should flush for at least 15 minutes. Consult your material safety data sheet for specific instructions.

Housekeeping

Good housekeeping should be practiced in the work area. Employees must be alerted to the need to clean UV-curable materials off of any con-

tacted surface immediately, so as to prevent the unknowing contamination of other employees.

Solvents should be used for cleaning equipment only if provision for vapor removal has been made, appropriate respiratory protection is worn and a safe means of disposal is available. Disposable wiping towels should be used rather than reusable rags and should be discarded immediately.

Training

Employees must be trained in the hazards and control of UV-curable materials. Such training should be provided to new employees before they begin working and to other employees at least annually.

Clean-up Procedures

Organic solvents are normally required to clean equipment and tools. The following solvents are recommended:

- Isopropanol (IPA) – for most UV materials
- Acetone – for difficult to dissolve materials

IPA is a less aggressive solvent with a higher flash point, which makes its use preferred for health and safety considerations. Where better solvency is necessary, acetone will do a better clean-up job. A final wash with soap and water will remove the last traces of UV materials. Small parts can be cleaned most effectively in a vapor degreaser. Other solvents for UV-curable materials are ethyl lactate and ethyl acetate.

Worker safety, flammability, solvency, equipment materials, and cost are all factors to consider when selecting an appropriate solvent for clean-up. Solvent suppliers should be contacted for proper handling of solvents.

Cured coating will not dissolve in solvent. Solvents that can aid in cured coating removal include:

*U.S. National Institute for Occupational Safety and Health/Mine Safety and Health Administration

1,1,1 – Trichloroethane: has the lowest flammability of suitable candidates. Relatively low in toxicity compared to other chlorinated solvents.

Dimethyl formamide (DMF): Possible reproductive effects. Consult supplier for details.

Dimethyl sulfoxide (DMSO): Readily absorbed through the skin.

N-methyl pyrrolidone

Caustic wash, 10% NaOH or KOH. Recommended for stainless steel, not glass.

The surface to be cleaned should first be tested with the cleaning solvent before use, as these solvents are capable of dissolving certain rubbers and plastics.

When handling objects fabricated from DSM Somos® resins in a partially cured state (after initial laser cure), wear nitrile or other chemical resistant gloves to avoid skin contact. The fabricated objects should be thoroughly washed with solvent (e.g. tripropylene glycol monomethyl ether, isopropyl alcohol) followed by post exposure to UV light and/or an oven bake at temperatures above 130°C. These post-cured objects may be handled without gloves. When sanding fully cured surfaces, suitable respirator protection for dust should be used.

Vapor degreasers have proven the most effective means of cleaning coating applicators and their associated parts.

Safe handling procedures should be followed during clean-up. Consult the specific Material Safety Data Sheet of the solvent supplier for handling information.

Spill Control

Small spills can be cleaned up using disposable towels, rags or an absorbent material such as sawdust, clay,

diatomaceous earth, etc., which should then be placed in a sealed, marked container. The spill area can then be cleaned with an approved cleaning agent, followed by a thorough washing with soap and water.

Large spills. The following procedures are recommended when cleaning up a large spill:

A. Clean-up personnel must wear protective clothing and NIOSH/MSHA approved respiratory equipment. Insure that adequate oxygen levels are maintained.

B. The area should be isolated immediately and diked to contain the spill.

C. The spill should be covered with absorbing material such as sawdust, clay, diatomaceous earth, earth, etc.

D. When the absorbant is saturated, it should be sealed in a marked container and disposed of properly.

E. The spill area should be thoroughly cleaned with solvent or soap and water and the waste disposed of properly.

Worker Clean-up

A. UV-curable materials should be wiped off protective clothing with clean disposable towels.

B. Protective clothing should be removed in this order: boots, gloves, face protection, and suit. After removing gloves, use disposable towels to protect your hands from contact with the UV/EB liquid coating material.

C. Place contaminated clothing in a sealed container for proper disposal.

D. All personnel should shower with soap and cool water.

disposal hazards. Nonetheless, some areas may still regulate cured coatings as hazardous industrial waste. Contact the governmental body in your area which regulates waste disposal to determine the specific requirements for cured UV coating waste.

Partially or uncured UV material waste may be classified as hazardous in some areas, thereby requiring special packaging, transportation and disposal. Check with the governmental body which regulates waste disposal in your area to ascertain what, if any, specific disposal requirements exist.

The packaging, transportation and disposal methods which are used must prevent any form of human contact with the waste, even if it is classified as nonhazardous or unregulated. This precludes the use of disposal methods which will result in groundwater or surface water contamination.

Clean-up solvents (containing UV-curable material) should be isolated in a sealed, marked container and disposed of as "Hazardous Waste" in accordance with all applicable laws and regulations.

Clean-up materials, soiled clothing, empty containers, etc., should be disposed of in accordance with the preceding guidelines. Whenever any of these contain uncured or partially cured UV-curable materials, the disposal method must preclude any form of human contact, including any which could result in groundwater or surface water contamination. Generally, non-solvent containing UV-curable materials may be disposed of as non-hazardous waste. Contact a reputable waste hauler for a complete analysis and classification of all waste streams.

A. Discard contaminated shoes by isolating in a sealed container and disposing of as solid waste in accordance with local legislation.

Disposal & Maintenance

Fully cured UV materials ordinarily present no safety or health related



B. Empty plastic bottles should be punctured, drained thoroughly and disposed of as solid waste.

C. Empty drums should be drained, triple rinsed and sent to a qualified drum reconditioner.

Maintenance

Maintenance employees must be informed about the hazards of UV-curable materials prior to working on UV associated equipment or performing other duties which may result in exposure to UV- materials.

Whenever possible, maintenance work should not be performed until the equipment has been thoroughly cleaned of UV-curable materials. Tools which may be contaminated with UV-curable material must be thoroughly cleaned prior to reuse.

Fire Fighting

Extinguishing media that should be used on fires involving these materials are National Fire Protection Association Class B extinguishers such as carbon dioxide, dry chemical or foam.

Vapors and combustion produced from burning UV-curable materials can be irritating to the respiratory system and must be avoided. If it is necessary to approach a fire or smoldering UV-curable material, wear eye, skin and respiratory protection equipment such as a NIOSH/MSHA approved self-contained breathing apparatus.

Water may be used to cool closed containers to prevent pressure buildup and possible auto ignition or explosion when exposed to extreme heat. If water is used, fog nozzles are preferable.

First Aid

This section includes first aid procedures in the event of human exposure to DSM Desotech UV-curable materials. Always refer to the DSM Desotech container label or Material Safety Data Sheet for information specific to the product being handled.

Skin

If UV-curable materials come in contact with the skin, immediately wash the contacted area thoroughly with soap and cool water while removing contaminated clothing. Particular attention should be paid to flushing the hair, ears, nose and other parts of the body that are not easily cleaned. The use of cool water is important to avoid opening the pores which may allow more material to penetrate the skin.

If large areas of skin have been exposed, or if prolonged contact with UV-curable materials results in blisters, a physician must be consulted.

During first aid procedures, avoid the accidental transfer of UV-curable material from the hands to other areas of the body, especially to the eyes. In the event of skin contact, do not reapply barrier cream until the skin has been completely cleansed.

Clothing should be professionally laundered. Do not launder contaminated clothing at home. Dispose of contaminated shoes, belts and other leather items because they may absorb UV-curable materials and re-expose the user at a later date.

Eyes

If eye contact occurs, flush the eyes immediately with large amounts of warm water for at least 15 minutes, followed immediately by a physician's examination.

Inhalation

Vapors from UV-curable materials, as well as their combustion products, can be very irritating to the respiratory system. Upon inhalation exposure to vapors or the products of combustion, immediately remove the victim to fresh air. If breathing has stopped, immediately begin artificial respiration or cardiopulmonary resuscitation. Get medical attention immediately.

Oxygen should be administered only by authorized personnel. The patient should be kept warm but not hot. An unconscious person should never be given anything by mouth.

Ingestion

If swallowed, consult the container label for specific instructions. Get medical attention immediately.

DSM Desotech Inc.
1122 St. Charles Street
Elgin, IL 60120
USA
Tel: (800) 223-7191 (USA)
Tel: +1-847-697-0400
Fax: +1-847-468-7785

DSM Desotech bv
P.O. Box 68
3150 AB Hoek van Holland
The Netherlands
Tel: +31-1743 15391
Fax: +31 1743 15530

DSM Somos®
2 Penn's Way, Suite 401
New Castle, DE 19720
Tel: +1-302-326-8100
Fax: +1-302-326-8121

DSM Desotech
Sales Representative Office
10A, China Overseas Building
No. 25, Chongqing Zhong Road
Shanghai 200020 CHINA
Tel: +86-21-6386-3080
Fax: +86-21-6386 1583

Japan Fine Coatings Co., Ltd.
3-7-10, Nihonbashi, Chuo-Ku
Tokyo, 103-0027
Japan
Tel: +81 3 5205 0181
Fax: +81 3 5205 0182

www.dsmdesotech.com
www.dsmsomos.com
www.dsm.com